# **ZONE CONTROL (2 TO 20 ZONES)**





### **DESCRIPTION**

ECOJAY SMARTZONE CONTROLLERS ARE CONFIGURABLE FOR ALL RESIDENTIAL EQUIPMENT TYPES UP TO 2 COOL AND 3 HEAT. ADJUSTABLE SETTINGS ENABLE SMARTZONE TO SATISFY A WIDE RANGE OF APPLICATIONS. SMARTZONE IS PERFECT FOR CHANGE-OUT, RETRO-FIT, NEW INSTALL AND UPGRADES. EASILY CONFIGURABLE TO SATISFY EQUIPMENT REQUIREMENTS AND INSTALL CONDITIONS OF ALL TYPES. SMARTZONE SAVES INSTALLATION TIME WITH SCREWLESS WIRING TERMINALS, PUSH BUTTON SETUP AND INTUITIVE DIPSWITCH CONFIGURATION. TROUBLESHOOTING IS SIMPLIFIED WITH THE FULL FUNCTION BRIGHTLY-LIT COLOR DISPLAY AND LED'S ON ALL WIRING CONNECTORS. MULTISTAGE THERMOSTATS ARE NOT NEEDED WITH ADJUSTABLE 'TIME & TEMPERATURE' STAGING CONTROLS. ADVANCED FRESH AIR, ECONOMIZER AND ECONOMY/AWAY MODE FEATURES OFFER MORE FLEXIBILITY AND VALUE.

### DIGITAL DISPLAY

THE LIGHTED FULL FUNCTION
DISPLAY CAN BE EASILY READ IN
BRIGHT OR DARK CONDITIONS AND
INDICATES SUPPLY TEMP, PURGE,
DELAY TIMER, ECO, HI/LOW TEMP
LIMIT, AND ADJUSTABLE SETTINGS.

### **USE ANY THERMOSTAT**

HEAT PUMP OR GAS / ELECTRIC ONLY SINGLE STAGE STATS NEEDED ZONE 1 CONTROLS EMER. HEAT FOR HEAT PUMP SPECS: MECHANICAL, BATTERY OR 24VAC W/ COMMON (5-WIRE) NOTE: STAGING WITH ZONE 1 STAT ONLY

### COLOR CODED LED INPUTS

LIGHT UP INDICATING CALLS FROM THERMOSTATS, ELIMINATING THE NEED FOR A VOLTMETER

## **ECONOMY/AWAY MODE**


EXCLUSIVE COMFORT AND EFFICIENCY CONTROL

### **ECONOMIZER**

USING AN OUTDOOR SENSOR ACCESSORY, SUBSTITUTE FRESH AIR FOR COOLING USING ZONE 4 SEE MORE IN ADVANCED FEATURES GUIDE

## FRESH AIR CONTROL

BUILT-IN FRESH AIR DAMPER CONTROL AND ENHANCED AIR CYCLER OPERATION (4X ONLY)



### PUSHBUTTON SETUP

USE SIMPLE BUTTON PUSH TO CONFIGURE TEMPERATURE SETTINGS, STAGING PARAMETERS, THERMOSTAT TYPE & FRESH AIR TIME

SUPPLY TEMP SENSOR INCLUDED FOR EQUIPMENT PROTECTION AND STAGING USING TIME & SUPPLY AIR TEMPERATURE



### **EXPAND TO 20 ZONES**

EXPAND TO 20 ZONES BY "SMART-LINKING" UP TO FIVE SMARTZONE-4X CONTROLLERS TO CREATE 8, 12, 16, OR 20 ZONE SYSTEMS

### CONTROL ANY EQUIPMENT

HEAT PUMP OR GAS / ELECTRIC INCLUDING DUAL FUEL UP TO 2 STAGE COOL AND 3 STAGE HEAT AUTOMATIC CHANGOVER

### **COLOR** CODED LED OUTPUTS

LIGHT UP INDICATING CALLS TO EQUIPMENT, ELIMINATING THE NEED FOR

### ANY 24VAC DAMPER

2- WIRE POWER CLOSE / SPRING OPEN OR SPRING CLOSE / POWER OPEN & 3- WIRE POWER CLOSE / POWER OPEN DAMPER POSITION INDICATED BY ) LEDS AND UP TO FOUR 2-WIRE OR TEN 3-WIRE DAMPERS ON EACH ZONE

ZS4X-2.0 SHOWN, ZS2X-2.0 ON BACK




ecojay.com 888-523-3265






# SMARTZONE

2 ZONE (ZS2X-2.0)






**DURABLE ABS PLASTIC ENCLOSURE END-VIEW** 

### SUPPLY TEMP SENSOR


WIRE LEAD AND PLUG-IN CONNECTOR



### MORE INFORMATION

- ► ECOJAY SMARTZONE INSTALL GUIDE
- ► ECOJAY SMARTZONE ADVANCED FEATURES
- ► THESE REFERENCES & MORE AVAILABLE AT ECOJAY.COM
- ► OR BY CALLING 1-888-523-ECOJAY (3265)
- ► VIDEOS AT ECOJAY.COM

## **SPECIFICATION**





- 3 NORMAL OR DUAL FUEL FOR HEAT PUMP
- 4 ALLOW 2ND STAGE ALWAYS OR ONLY WITH MORE THAN 1 ZONE

**ADJUSTMENT** 

- 5 FAN ELECTRIC ORFAN GAS
- 6 SMARTLINK EQUIPMENT (ZONES 1-4) OR ADDER ZONES (ZONES 5-20)
  - GAS/FLECT RVS. VLV. O NORMAL 2™ STAGE

**ZONES (1 - 4)** 

- **DUAL FUEL** LOCKOUT FAN GAS SMART LINK
  - ELECTRIC ZONES (5 - 20)

**HEAT PUMP** 

**▼LO TEMP Cut-Out** 

▲ HI TEMP Cut-Out

GAS/ELECTRIC

AUX HEAT Cut-In

ECONOMIZER Cut-Out

HEAT PUMP

LO TEMP / HI TEMP CUTOUTS (°F)

**48** [41 – 55]

135 [125 - 150]

120 [110 - 125]

90 [90 - 94]

60 [58 - 68]

**DELAY STATUS (TIME REMAINING SECONDS)** THERMOSTAT TYPE ECO (ECONOMY) STATUS / FRESH AIR (FLASH)



40

ADJUST SETTINGS